ONUS WOOD

Install guide: Wall sconces

General guidance for Onus Wood wall sconces. Your product may include extra instructions; where they differ, follow those.

1

Before you start

Hard-wired wall sconces must be installed by a licensed electrician, in line with AS/NZS 3000. Turn the power off at the switchboard before any work begins.

2

Check the parts

Unpack on a soft surface. You should have the sconce, the wall mounting plate and fixings. Ceramic and glass parts are packed separately; handle them with care.

3

Position

A comfortable height is about 1500 to 1700 mm to the centre in hallways, or 1100 to 1300 mm beside a bed. Make sure the wall point lines up with the plate.

4

Mount the plate

Fix the mounting plate level, into studs or with fixings rated for the wall type.

5

Connect and fit

Your electrician connects the supply at the plate. The timber body then hangs onto the plate and locks in place, with all fixings hidden.

6

Switch on

Fit the LED globe or module supplied, refit any glass or ceramic, restore power and test.

Safety: never install, adjust or clean a light with the power on. Use only the LED globes or modules specified for your product. If a cord, fitting or diffuser is damaged, stop using the light and contact us for a replacement part.

Applies to: Wollemi, Otway, Freycinet. Questions? hello@onuswood.com