ONUS WOOD

Install guide: Floor and task lamps

General guidance for Onus Wood floor and task lamps. Your product may include extra instructions; where they differ, follow those.

1

Before you start

Floor and task lamps plug into a standard power point. No electrician is needed.

2

Check the parts

Unpack on a soft surface. You should have the base, the stem, the head or shade, the cord with inline switch, and the LED globe or module.

3

Assemble

Where the stem ships separately, thread it into the base until it seats firmly. Don't over-tighten timber threads.

4

Fit the light

Fit the LED globe or module supplied, then fit any glass diffuser or shade.

5

Adjust

Task lamps with an aluminium ball joint can pivot and swivel. Use the tension knob to set how freely the joint moves.

6

Use

Place the lamp on a stable, level surface, away from water and heat. Unplug before cleaning or changing the globe.

Safety: never install, adjust or clean a light with the power on. Use only the LED globes or modules specified for your product. If a cord, fitting or diffuser is damaged, stop using the light and contact us for a replacement part.

Applies to: Barrington, Karijini, Daylesford, Bright, Lorne. Questions? hello@onuswood.com